Dialing your Isatphone Pro Phone

To access the Isatphone Satellite System
First, make sure the antenna is raise to a vertical position. Make sure the phone as a good view of the southern sky and turn it on. It will search for a satellite and attempt to register itself; the satellite icon in the upper left of the screen shows it is looking for the satellite. When it registers, it will show it in text on the screen. The signal strength is also shown during this process. Please read the owner guide for more details. If the signal strength is 2 bars or less, an attempted call will likely fail, please move to a better position.

How to dial telephone numbers
All telephone numbers must be preceded with the international country code, then the telephone number. For example in the US the country code is 1, so to call a US telephone number, enter: +1-area code-telephone number (hold the zero key for a two seconds and a "+" appears on the screen).
Press the "send" key to start the call process.

Calling your Isatphone ProTelephone
Someone calling your Isatphone Pro phone or pager, must treat it as an international call, so in the US the international access number is 011 (it is different in other countries). They must then dial 011-870-xxxx-xxxxx the call rate is determined by your telephone company but it is expensive.

Checking Voice Mail / Text Messages
Voice Mail alerts are automatically sent to the phone when it is turned on and the phone beeps at you to say you have a message(s). You check you Voice Mail by dialing your own Isatphone telephone number and pressing "570" or +870-7720-01899 <green button> when you hear the greeting and entering your password. You can check your Voice Mail from any phone by dialing the voicemail number (local calling rates apply).

 Text messaging to the telephone is free and done using standard email; with the phone's telephone number as the address 8707764xxxxx@message.inmarsat.com or use the Message Box on the Isatphone web site http://www.inmarsat.com/Services/Land/IsatPhone/

Popular International Country Codes

Algeria 213	Finland 358	Korea 82	Qatar 974
Am Samoa 684	France 33	Kuwait 965	Romania 40
Argentina 54	French Antilles 596	Liberia 231	Russia 7
Armenia 374	French Polynesia 689	Libya 218	Saudi Arabia 966
Australia 61	Gabon 241	Luxembourg 352	Senegal 221
Bahrain 973	Georgia 995	Macedonia 389	Singapore 65
Belarus 375	German 49	Malawi 265	Slovak 421
Belgium 32	Greece 30	Malaysia 60	Slovenia 386
Belize 501	Greenland 299	Inmarsat 870	South Africa 27
Bolivia 591	Guam 671	Iridium 881	Spain 34
Bosnia 387	Guatemala 502	Mexico 52	Sri Lanka 94
Brazil 55	Guyana 592	Morocco 212	Suriname 597
Cameroon 237	Haiti 509	Netherlands 31	Sweden 46
Canada 1	Herzegovina 387	Neth. Antilles 599	Switzerland 41
Chile 56	Honduras 504	New Caledonia 687	Taiwan 886
China 86	Hong Kong 852	New Zealand 64	Thailand 66
Columbia 57	Hungary 36	Nicaragua 505	Tunisia 216
Costa Rica 506	Iceland 354	Nigeria 234	Turkey 90
Croatia 385	India 91	Norway 47	Ukraine 380
Cuba 53	Indonesia 62	Oman 968	United Arab Em 971
Cyprus 357	Iran 98	Pakistan 92	United Kingdom 44
Czech 420	Iraq 964	Panama 507	USA 1
Denmark 45	Ireland 353	Papua New Guinea 675	Uruguay 598
Ecuador 593	Israel 972	Paraguay 595	Venezuela 58
Egypt 20	Italy 39	Peru 51	Vietnam 84
El Salvador 503	Ivory Coast 225	Philippines 63	Yugoslavia 381
Ethiopia 251	Japan 81	Poland 48	
Fiji Islands 679	Kenya 254	Portugal 351	